




## QUICK START GUIDE

### TouchLink Dual Band Wi-Fi Router



#### OVERVIEW



- 1 LED Indicator
- 2 WPS Button
- 3 Turbo Button
- 4 Power Port
- 5 Reset Button
- 6 WAN Port
- 7 LAN Ports
- 8 USB Port
- 9 On/Off Switch

#### WPS Button:

Press and hold 2 seconds for WPS one-key encryption and connection

#### Reset Button:

Press and hold 6 seconds for system reset.

01

#### BASIC INFO

Default IP: [192.168.10.1](http://192.168.10.1)  
 Login: <http://wifi.wavlink.com>  
 Default Password: **admin**  
 Official Website: [www.wavlink.com](http://www.wavlink.com)  
 Technical support: [support@wavlink.com](mailto:support@wavlink.com)

#### AC1200/AC2100

2.4G SSID: **WAVLINK-N**  
 5G/AC SSID: **WAVLINK-AC**  
 Touchlink SSID: **WAVLINK\_Touch**



#### WAVLINK APP

#### AC3000

2.4G SSID: **WAVLINK-N**  
 5G/AC SSID: **WAVLINK-AC**  
**WAVLINK-AC-1733M**  
 Touchlink SSID: **WAVLINK\_Touch**

#### AC4300

2.4G SSID: **WAVLINK-N-800M**  
 5G/AC SSID: **WAVLINK-AC1-1733M**  
**WAVLINK-AC2-1733M**  
 Touchlink SSID: **WAVLINK\_Touch**

#### LED INDICATION

##### WAVLINK logo LED


LED	Status	Description
Blue	Solid	The internet connection is normal.
	Flash	Touchlink or WPS is activated.
Red	Flash	The router is not connected.

02

LED	Status	Description
Power	On	The router is powered on.
	Off	The router is powered off.
WAN/LAN	On	A device is connected to the port.
	Off	No device is connected to the port.
WiFi	On	The WiFi works normally.
	Off	The WiFi is off.

#### NETWORK CONFIGURATION

1. Connect the router to LAN port of modem or an upstream router.



#### 2. Connection


##### 2.1 Via Wireless

Turn on your Wi-Fi, search SSID (as in Basic info), and connect to it; then you can start configuring.



03

#### 2.2 Via Cable



Connect your laptop to LAN port of this router then you can start configuring.

3. Launch a browser from your laptop/PC or smart phone and enter [wifi.wavlink.com](http://wifi.wavlink.com) or [192.168.10.1](http://192.168.10.1) in the address field. The default password is **admin**.




4. Select your Region, for your network security, we suggest you set a new login password following the rules accordingly.

04



5. Proceed to "Wizard" section and choose "Router" mode.

6. Select the WAN Type according to the type of your network.




05

#### Which WAN Type am I supposed to choose?

If you use DSL line and you are only provided an account name and a password by your ISP, choose **PPPoE**. If you use cable TV or fiber cable, choose **DHCP(Dynamic IP)**. If you are provided information such as IP address, Subnet Mask and Default Gateway, choose **Static IP**.

7. You can either continue using or change the default SSID. As for Security Type, we usually suggest that users choose "WPA/WPA2 Mix (Recommended)". For network security, we suggest you create a Password for your Wi-Fi.




8. Click on "Apply" and wait for the installation process to complete.

06

#### TOUCHLINK TECHNOLOGY

Touchlink is the patented technology of Wavlink. At the top of the router there is the Touchlink sensing pad; once you touch the pad with your hand or other devices, the sensing pad will blink blue indicating that Touchlink is in process, then you can search "WAVLINK\_Touch" and connect to it without any password.



#### Note:

Touchlink works for smart phone, tablet computer, laptop, etc.

07

#### FIRMWARE UPGRADE

If you need to update firmware, please proceed as the following steps:

1. Download the latest firmware file from Wavlink website.
2. Extract the firmware from the downloaded file.
3. Log in to [192.168.10.1](http://192.168.10.1) or [wifi.wavlink.com](http://wifi.wavlink.com), then choose "Setup" and select "Upgrade Firmware".



4. Click on **Browse** to locate the extracted firmware file.
5. Click on **Apply**, and wait for the firmware upgrade process to complete.

#### What is firmware upgrade and why do I need it?


Firmware fixes bugs for your device, contains new features, and improves the experience of using the product. For your device update and security, please ask us for help. Wrong upgrade may damage your device and void the product warranty.

For more details, please visit our website [www.wavlink.com](http://www.wavlink.com)  
Our Technical Support: [support@wavlink.com](mailto:support@wavlink.com)

08


#### Turbo button

On the right bottom area there is a Turbo button. You can press it for optimum performance and the WAVLINK LED light flashes about 5 seconds.



#### USB button


You can use the USB port for media or storage across your local network.




Turbo button

09

#### Location



We suggest that you put the router in a relatively open area without many obstacles such as concrete walls, metal objects and so on; you can put it on a shelf or a TV stand if possible.



We suggest that you stretch all antennas as shown in the picture above if you want to mount this router on the wall.

10

#### FAQ

##### Q1. Why doesn't the login page appear after entering <http://wifi.wavlink.com>?

- Make sure your PC is set to obtain IP address automatically.
- Please make sure you entered the correct website.
- Reboot your device and try again.

##### Q2. What can I do if I can not access the Internet?

- Make sure your Internet works normally, please contact your ISP(Internet Service Provider) if it doesn't.
- Initiate your browser, enter [192.168.10.1](http://192.168.10.1) or [wifi.wavlink.com](http://wifi.wavlink.com), then set up following the quick start guide.
- Reboot your device and try again.

##### Q3. What should I do if I can't have access to [192.168.10.1](http://192.168.10.1) or [wifi.wavlink.com](http://wifi.wavlink.com) on my android phone?

- We suggest you turn off your 4G signal first before you set up the network, then turn it on when the configuration is done.

##### Q4. What can I do if I forget my administration management password?

- Please reset the device, the default password is admin.

##### Q5. How do I find the best location for the router?

- Please put your mesh devices in a relatively open space to avoid obstacles such as metal objects, reinforced concrete walls and so on.

Please visit [https://www.wavlink.com/en\\_us/faq.html](https://www.wavlink.com/en_us/faq.html) for more details.

11

#### GNU GENERAL PUBLIC LICENSE NOTICE

This product includes software codes developed by third parties. These software codes are subject to either the GNU General Public License (GPL), Version 2, June 1991 or the GNU Lesser General Public License (LGPL), Version 2.1, February 1999. You can copy, distribute, and/or modify in accordance with the terms and conditions of GPL or LGPL.

The source code should be complete, if you want us to provide any additional source code files under GNU General Public License (GPL), please contact us in these matters. We are committed to meeting the requirements of the GNU General Public License (GPL).

You are welcome to contact us local office to get the corresponding software and licenses. Please inform us your contact details (full address) and the product code. We will send you a software package with the software and license for free. The respective programs are distributed WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. Please refer to the GNU General Public License website for further information.

<http://www.gnu.org/licenses/old-licenses/lgpl-2.0.html>  
<http://www.gnu.org/licenses/gpl.html>

#### WEEE Directive & Product Disposal

At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.

12



Thank you for purchasing WAVLINK product!



WAVLINK (@WavlinkOfficial)  
WAVLINK SUPPORT (@WavlinkTechSupport)