



Quick Start Guide

AC1200 Dual Band Full Gigabit WiFi Router



kb.wavlink.xyz/docs/QUANTUM-DAG/v100/InstallationConfigurationUpdate

Scan the QR code or load the link for Detailed Guide downloading



WAVLINK (@WavlinkOfficial)
WAVLINK SUPPORT (@WavlinkTechSupport)

QUANTUM DAG

Safety Instructions

Always read the safety instructions carefully.
Keep this Quick Start Guide for future reference.
Keep this equipment away from humidity.
If any of the following situation arises, get the equipment checked by a service technician:

- The equipment has been exposed to moisture.
- The equipment has been dropped and damaged.
- The equipment has obvious sign of breakage.
- The equipment has not been working well or you cannot get it work according to Quick Start Guide.

Copyright Statement

No part of this publication may be reproduced in any form by any means without the prior written permission.
Other trademarks or brand names mentioned herein are trademarks or registered trademarks of their respective companies.

Disclaimer


Information in this document is subject to change without notice.
The manufacturer does not make any representations or warranties (implied or otherwise) regarding the accuracy and completeness of this document and shall in no event be liable for any loss of profit or any commercial damage, including but not limited to special, incidental, consequential, or other damage.

WEEE Directive & Product Disposal

 At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.

01

Overview



- ① 2 x 1000Mbps LAN ports
- ② 1 x 1000Mbps WAN port
- ③ WPS/Reset Button
- ④ Power port

Basic Info

Default IP: 192.168.20.1
Login: <http://wavlogin.link>
2.4G SSID: WAVLINK-N_XXXX
5G SSID: WAVLINK-AC_XXXX
Official Website: www.wavlink.com
Technical Support: support@wavlink.com


02

In the Box

- 1 x AC1200 Dual Band Full Gigabit Wi-Fi Router
- 1 x Power Adapter
- 1 x Ethernet Cable
- 1 x Quick Start Guide

Setup Guide

1. Connect your modem to the Internet, connect router's WAN port to the Modem's or other routers' LAN port, then plug it in a power outlet.



2. Connect the Wi-Fi signal of WAVLINK device. The Wi-Fi name should be WAVLINK-XXXXX.



For Windows Users

For Mac Users

03

3. Disconnect other Internet connection including Ethernet cable or VPN from the PC/laptop, then open the web browser and enter <http://wavlogin.link> or 192.168.20.1 in the address bar.



4. Log in the management page and follow the web instruction to configure the device.

FAQ

Q1. How to reset the router?

- Please press the reset button for 6 seconds.

Q2. What should I do if I could not log in the management page of the WAVLINK device?

- Please make sure you should connect the Wi-Fi signal of the WAVLINK device, the WiFi name of the WAVLINK device should be WAVLINK-XXXX.
- Try to log in the management page with other devices like PC / laptop or phone.
- Try to use <http://wavlogin.link> or <http://192.168.20.1> to log in the management page.
- Please try to reset the device and then log in the management page again.
- Try to use another browser to log in the management page.

Q3. How to configure the WAVLINK device as AP/repeater mode?

- Please scan the QR code for detailed user manual.

Q4. What should I do if I forget the Wi-Fi password or management page password?

- If you forget the Wi-Fi password, please connect the LAN port of the router to your PC via Ethernet cable, then log in the management page and go to wireless. Next you could check the Wi-Fi password.
- If you forget the management page password, please reset the device and then you could create a management page password.

04

GNU General Public License Notice

This product includes software codes developed by the third parties. These software codes are subject to either the GNU General Public License (GPL), Version 2, June 1991 or the GNU Lesser General Public License (LGPL), Version 2.1, February 1999. You can copy, distribute, and/or modify in accordance with the terms and conditions of GPL or LGPL. The source code should be complete, if you want us to provide any additional source code files under GNU General Public License (GPL), please contact us in these matters. We are committed to meeting the requirements of the GNU General Public License (GPL). You are welcome to contact our local office to get the corresponding software and licenses. Please inform us your contact details (full address) and the product code. We will send you a software package with the software and license for free. The respective programs are distributed WITHOUT ANY WARRANTY, without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. Please refer to the GNU General Public License Website for further information.

<http://www.gnu.org/licenses/old-licenses/lgpl-2.0.html>
<http://www.gnu.org/licenses/gpl.html>

WEEE Directive & Product Disposal

 At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.

05

Need help?

We're here for you!



Online support: wavlink.com

Available Mon-Fri 8:30 am-5:30pm (UTC+8)



support@wavlink.com

Available Mon-Fri 8:30 am-5:30pm (UTC+8)



+1 8889730883 (US Local)

Mon-Fri 9:00 am - 10:00 pm (UTC-5)

www.wavlink.com



Thank you for purchasing
WAVLINK product!

WN530HG4-B说明书WAVLINK-E2

105g铜版纸四色印刷，正反印，风琴折

产品尺寸72X106mm 展开尺寸288*106mm