WAVLINK
see the world

QUICK START GUIDE
BE6500 WiFi 7 Tri-Band PCIe Adapter

www.wavlink.com/en_us/WL-WN922BE3
Scan the QR code or load the link for
Quick Start Guide and Driver downloading

WL-WN922BE3

WAVLINK (@WavlinkOfficial)
WAVLINK SUPPORT (@WavlinkTechSupport)

- 1 -

Introduction

Wavlink Wi-Fi 7 Tri-Band PCI-E is a BE6500 wireless adapter for desktops that supports the latest Bluetooth 5.4. It has the MLO feature that effectively reduces signal interference and transmission delays, providing a faster and more reliable wireless networking experience. Compliant with 802.11 BE specification, the wireless adapter supports 2.4G, 5G and 6G bands. With 4096-QAM and MU-MIMO technology, WL-WN922BE3 delivers wireless signal faster and more effective by cooperating with a MU-MIMO compatible router.

In the Box

- 1 x BE6500 WiFi 7 Tri-Band PCIe Adapter
- 1 x Bluetooth Cable
- 1 x Installation Guide Card
- 2 x External Antennas
- 1 x Low Profile Bracket
- 1 x Quick Start Guide
- Several Screws

System Requirements

- Microsoft Windows 11 64 bit

Installation

1. Unplug your PC and remove the case panel.

2. Connect the Bluetooth cable to the adapter.

Adapter

Bluetooth cable

- 2 -

3. Find the corresponding PCI-E slot, then inset the adapter carefully.

4. Find an available F_USB slot then carefully connect the Bluetooth cable to it.

- 3 -

5. Mount the external antenna to the adapter base.

6. At last install back the PC case panel then you can get ready to install the driver.

Driver Setup

After installation, please visit the following website to download the latest driver for PCI-E adapter.
www.wavlink.com > SUPPORT > Driver > Wireless > PCI-E Adapter > WL-WN922BE3

- 4 -

1. Unzip the file to find "Realtek PCI-E Wireless WiFi7 WiFi-24.12.0-Driver64-Win11.exe". It is for Bluetooth/Wi-Fi connection. Please double-click it for driver setup.

Realtek PCI-E Wireless WiFi7 WiFi-24.12.0-Driver64-Win11.exe   Application   59,607 KB

2. Click "Install" to start the installation, then wait patiently for the installer to complete the setup process.

WAVLINK
Welcome to Realtek PCI-E Wireless WiFi7 WiFi-24.12.0-Driver64-Win11 1.1.1.1

Setup will guide you through the installation of Realtek PCI-E Wireless WiFi7 WiFi-24.12.0-Driver64-Win11 1.1.1.1.

It is recommended that you close all other applications before starting Setup. This will make it possible to update relevant system files without having to reboot your computer.

Click Install to start the installation.

Install   Cancel

- 5 -

Installing
Please wait while Realtek PCI-E Wireless WiFi7 WiFi-24.12.0-Driver64-Win11 1.1.1.1 is being installed.

Output folder: C:\Program Files (x86)\Realtek PCI-E Wireless WiFi7 WiFi-24.12.0-Wir

< Back   Next >   Cancel

3. After the installation is complete, please click "Finish".

WAVLINK
Completing Realtek PCI-E Wireless WiFi7 WiFi-24.12.0-Driver64-Win11

Realtek PCI-E Wireless WiFi7 WiFi-24.12.0-Driver64-Win11 1.1.1.1 has been installed on your computer.

Click Finish to close Setup.

< Back   Finish   Cancel

- 6 -

Wi-Fi Configuration

Step 1: When the computer turned on, insert the wireless card into an open USB port.
Step 2: Left-click network icon in the task bar to turn on the new WiFi.

← Wi-Fi

WAVLINK-AC_09B8

WAVLINK-AX_0091
Secured

Enter the network security key

You can also connect by pushing the button on the router.

Next   Cancel

Windows 11

NOTE:
Firstly you need to find the right WLAN name of your WL-WN922BE3 then you can set it up if necessary, you can also change the name in "Network Connections".

- 7 -

Need help?
We're here for you!

Online support: wavlink.com
Available Mon-Fri 8:30 am-5:30pm (UTC+8)

support@wavlink.com
Available Mon-Fri 8:30 am-5:30pm (UTC+8)

+1 8889730883 (US Local)
Mon-Fri 9:00 am - 10:00 pm (UTC-5)

www.wavlink.com

Thank you for purchasing
WAVLINK product!

名称：WL-WN922BE3说明书WAVLINK-E1

成品尺寸：80X110mm   展开：400X110mm

材质工艺：105g铜版+4C正反双面印刷+风琴折

修改时间：

备注：2024.11.09 高瑶