



Quick Start Guide

AC1200 Dual Band Gigabit Wi-Fi Router




www.wavlink.com/en_us/QUANTUM-D4P
Scan the QR code or load the link for
Quick Start Guide downloading

QUANTUM D4P



WAVLINK (@WavlinkOfficial)
WAVLINK SUPPORT (@WavlinkTechSupport)

Overview



- 1 LED Indicator
- 2 Pair Button
- 3 Turbo Button
- 4 Power Port
- 5 Reset Button
- 6 WAN Port
- 7 LAN Ports
- 8 USB Port
- 9 On/Off Switch

Pair Button:

Press and hold 2 seconds for Pairing connection

Reset Button:

Press and hold 6 seconds for system reset.

Basic Info

Default IP: **192.168.10.1**
Login: <http://wifi.wavlink.com>
Default Password: **admin**
Official Website: www.wavlink.com
Technical Support:
support@wavlink.com

SSID:
2.4G: **WAVLINK-Mesh_XXXX**
5G: **WAVLINK-Mesh_XXXX**
TouchLink SSID:
WAVLINK_Touch


01

LED Indication

PWR	Solid on: The router is powered on. Off: The router is not receiving electrical power.
WAN/LAN	Solid on: A powered-on device is connected to the port. Off: No device is connected to this port.
WiFi	Solid on: The WiFi is on. Off: The WiFi is off.

Network Configuration


1. Connect the router to **LAN** port of modem or the upstream router.



2. Connection


- 2.1 Via Wireless

Turn on your Wi-Fi, search SSID as in **Basic Info**, and connect to it; then you can start configuring.




For Windows users

02



For Mac users

2.2 Via Cable




Connect your laptop to LAN port of this router then you can start configuring.

3. Launch a browser from your laptop/PC or smart phone and enter wifi.wavlink.com or **192.168.10.1** in the address field. The default password is **admin**.




4. Select your **Country/Region** and **Time Zone**. For your network security, we suggest that you set a new login password.

03




Note: The three colored bars in "Password strength" area indicates the strength of the login password.

5. Then you can change your SSID or use the default one. As for **Encryption Mode**, if your device supports **WPA3/WPA2-MIX**, we suggest you choose "**WPA3/WPA2-MIX**". For network security, please set a **Password** according to the rules.



6. The system will then guide you to the **Network** page for the **Mode selection** and **WAN Type**, and click **Save**.

04



Which WAN Type am I supposed to choose?

If you use DSL line and you are only provided an account name and a password by your ISP, choose **PPPoE**. If you use cable TV or fiber cable, choose **DHCP(Dynamic IP)**. If you are provided information such as IP address, Subnet Mask and Default Gateway, choose **Static IP**.

7. Click **Apply**. Installation and basic setup take a few minutes to complete.


Mesh Agent Mode

In WAVLINK Mesh system, you can also set this router as the Mesh Agent Mode (similar to repeater mode) and connect the router to another existing Mesh controller.

Please configure according to the following steps:

1. Log in to **192.168.10.1** or wifi.wavlink.com.
2. In **Mode selection**, please choose "**EasyMesh Agent Mode**".
3. Click on the "**Start Pairing**" button.

05



4. Now please start pairing process on the Mesh controller.

Note:

*If you need to switch this device from Agent mode back to router mode, then you have to manually reset the router.
**If you use the LAN Backhaul mode, our device detects the Mesh mode automatically, therefore, the pairing process is not necessary.


More Mesh Devices

Generally, a mesh router device supports up to **7** (including the existing device). Therefore, if you need to add more mesh devices to build up a stable network in your home, you simply need to pair the new mesh devices with the existing network.

Option I


1. Log in to wifi.wavlink.com or **192.168.10.1**.
2. "**Advanced**" -> "**Mesh Network**".
3. You can add extra devices by entering their "**Pair Key**".

06



Option II


After configuring the main router, please configure the sub-router according to the EasyMesh Agent Mode part. After configuring the sub-router, please keep pressing the pair button of the main router for **2 seconds**. When LED lights become solid blue, the pairing process is successfully completed.



07

TouchLink Technology

TouchLink is the patented technology of Wavlink. At the top of the Router device there is the TouchLink sensing pad; once you touch the pad with your hand or other devices, the sensing pad will blink blue, indicating that TouchLink is in process, then you can search "**WAVLINK_Touch**" and connect to it without any password.




Note:

Unlike your regular Wi-Fi network that you and your family members use, the guest Wi-Fi network restricts what your guests can do in your network. Specifically, it gives visitors access to your Internet connection and nothing else. They can't see any of your devices on the network and they don't have the ability to access them. Most importantly, they can't accidentally introduce malware or compromise your devices or data in any other way. **TouchLink** works for smart phone tablet computer, laptop, etc. If you want to change the configuration of **TouchLink**, then you can do as follows:

08

1. Log in to **192.168.10.1** or wifi.wavlink.com, then choose "**Advanced**" and select "**Guest Wi-Fi**".
2. The default **Guest Wi-Fi Mode** is **TouchLink**.
3. The length of TouchLink time (Duration) can be set to 30s, 120s and 240s, the default is 120s.
4. You can also set the length of time (Use Time) for your guests.



Firmware Upgrade

If you need to update firmware, please proceed as the following steps:


Option I

1. Download the latest firmware file from Wavlink website.
2. Extract the firmware from the downloaded file.
3. Log in to **192.168.10.1** or wifi.wavlink.com, then choose "**Advanced**" and select "**Firmware Update**".
4. Click on to locate the extracted firmware file.
5. Click on "**Upload**" and choose "**Apply**", and wait for the firmware upgrade process to complete.

09

Option II

1. Log in to **192.168.10.1** or wifi.wavlink.com, then choose "**Advanced**" and select "**Firmware Update**".
2. Click on "**Check New Version**" to find the latest version.
3. Click on "**Download and Upgrade**", and wait for the firmware upgrade process to complete.



What is firmware upgrade and why do I need it?

Firmware fixes bugs for your device, contains new features, and improves the experience of using the product. For your device update and security, please ask us for help. Wrong upgrade may damage your device and void the product warranty. For more details, please visit our website www.wavlink.com. Our Technical Support: support@wavlink.com

10

FAQ

Q1. Why doesn't the login page appear after entering <http://wifi.wavlink.com>?

- Make sure your PC is set to obtain IP address automatically.
- Please make sure you entered the correct website.
- Reboot your device and try again.

Q2. What can I do if I can not access the Internet?

- Make sure your Internet works normally, please contact your **ISP**(Internet Service Provider) if it doesn't.
- Initiate your browser, enter **192.168.10.1** or wifi.wavlink.com, then set up following the quick start guide.
- Reboot your device and try again.

Q3. What should I do if I can't have access to **192.168.10.1** or wifi.wavlink.com on my android phone?

- We suggest you turn off your 4G signal first before you set up the network, then turn it on when the configuration is done.

Q4. What can I do if I forget my administration management password?

- Please reset the device, the default password is **admin**.

Q5. How do I find the best location for mesh devices?

- Please put your mesh devices in a relatively open space to avoid obstacles such as metal objects, reinforced concrete walls and so on.

Q6. Why the flow monitoring is inaccurate?

- The Hardware NAT Settings's default open status leads to the absence of monitored data. If you wanna keep the flow monitoring accurate, you have to turn off the **Hardware NAT** CPU usage function manually, which inevitably will increase the CPU usage.

11

GNU GENERAL PUBLIC LICENSE NOTICE

This product includes software codes developed by third parties. These software codes are subject to either the GNU General Public License (GPL), Version 2, June 1991 or the GNU Lesser General Public License (LGPL), Version 2.1, February 1999. You can copy, distribute, and/or modify in accordance with the terms and conditions of GPL or LGPL. The source code should be complete, if you want us to provide any additional source code files under GNU General Public License (GPL), please contact us in these matters. We are committed to meeting the requirements of the GNU General Public License (GPL).

You are welcome to contact us local office to get the corresponding software and licenses. Please inform us your contact details (full address) and the product code. We will send you a software package with the software and license for free. The respective programs are distributed WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. Please refer to the GNU General Public License website for further information.

<http://www.gnu.org/licenses/old-licenses/lgpl-2.0.html>
<http://www.gnu.org/licenses/gpl.html>

WEEE Directive & Product Disposal

At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.

12



Thank you for purchasing
WAVLINK product!

Official website: www.wavlink.com
Technical support: support@wavlink.com

13